
100
110
130
120
Computer or other Device
-
+
switch
-
+
Battery or Power Supply or Direct Power in
Switch can be located on Biometric Reader on the Device or Computer, or on the Power Supply, or Seperate
140
Biometric Reader Turns Switch ON

FIGURE 1